

# ECONOMY BUNDING



## INSTALLATION INSTRUCTIONS

SpillTech® Economy Bunding enables you to build your own bunded area, quickly and cost effectively, to stop spills going down the drain and helping you comply with the HSNO Act. SpillTech® Economy Bunding is perfect for installing across warehouse and factory doorways or creating a customised bunded area to store liquids.

Constructed from heavy duty EVA foam, SpillTech® Economy Bunding will compress slightly when driven over then pop back into shape. The trapezoid profile makes it easy for pallet jacks and trolleys to pass over the bunding without disturbing the load.



- Make sure the surface you wish to adhere the SpillTech® Economy Bunding to is clean and dry before using the adhesive.



- SpillTech® Economy Bunding comes in 2 meter lengths. Before applying the adhesive cut the bunding to the desired length ensuring a tight fit from wall to wall so there are no gaps for liquids to pass through.
- SpillTech® Economy Bunding can be mitred to create corners if desired.



- We recommend you use ADOS F22 to adhere SpillTech® Economy Bunding to concrete or vinyl flooring.
- Make sure to follow the instructions carefully.
- Use the brush provided (in the lid) to apply adhesive to both surfaces and allow the surfaces to become tacky before fastening (5-15 minutes).
- The adhesive can also be used to adhere each 2 meter length of SpillTech® Economy Bunding together if desired.



- Once the adhesive has become tacky carefully position the SpillTech® Economy Bunding in place.
- Make bond by pressing components firmly together taking care to expel any air bubbles.
- Allow to cure for 24 hours.



To find a SpillTech® Economy Bunding distributor near you, contact:

**DALTON INTERNATIONAL LIMITED**

Physical Address: Unit 6, 23 Ash Road, Wiri, Auckland, 2104

Tel: 0800 323 223 or +64 09 263 3142 | Web: [www.daltoninternational.co.nz](http://www.daltoninternational.co.nz) | Email: [enquiries@dilnz.co.nz](mailto:enquiries@dilnz.co.nz)