



SHIGEMATSU TS01 RESPIRATOR QUICK GUIDE

This half-face respirator is compatible with STS “Y Series” filters with twist connectors YABEK1P3R and YP3R.

The built in fit checker allows for an easy to perform fit check without using additional parts.

CHECKLIST PRIOR TO USE:

1. Check that all parts are attached correctly and firmly.
2. Check that the inhalation and exhalation valves are not stuck and are free from tears and rips.
3. Check that there are no defects, deformation, cracks or holes
4. Check the headband to make sure it is sufficiently elastic.
5. Check and attach the filter to the front of the mask.

DONNING:

1. Hold both ends of the headband with the white line of the head harness facing inwards and disconnect the buckle.
2. Place the headband over your head and hold both ends of the headband near the buckle
3. Pull the ends evenly so that the respirator is positioned over your mouth and nose.
4. Connect the buckle behind your neck and pull the straps until you get a comfortable and secure fit.

FIT CHECK:

1. Turn fit checker on by pushing the blue lever on each side of the mask forward.
2. Remove hands from the mask and gently inhale.
3. The respirator should slightly collapse inward and create a vacuum. Check that there is no air leaking between the respirator and your face.
4. Turn fit checker off by pulling the blue levers back towards the face.
5. If you detect an air leak, reposition the respirator and readjust the tension of the head harness until a vacuum seal is achieved to eliminate leakage. Do not use the respirator if a good seal cannot be achieved.

LOOKING AFTER YOUR RESPIRATOR:

1. To clean the respirator, start by removing all filters and using alcohol-free wipes or a small brush with warm water and mild dish soap.
2. After cleaning, rinse with disinfectant and then clean water to remove any excess disinfectant and minimise skin irritation.
3. Dry on a rack or clean surface with the respirator rubber facing up so it does not deform as it dries.
4. Once dry, check for any damage, cracked rubber or worn straps. If any significant wear and tear is found, do not wear the respirator and replace the damaged parts.
5. Storage - when not in use remove filters and place respirator inside the plastic box and ensure it is sealed.

CHANGING YOUR FILTERS:

1. Depending on use, it is recommended that filters are changed every three months.
2. Write the expiry date on the filters so you know when they need to be changed
4. If you are struggling to breathe when the mask is on, this may indicate that the filters are full and need to be replaced.
5. You can reorder TS01 Dust Particulate filters on the [rifftsafety](http://rifftsafety.co.nz) website. The reorder code is SKU:STS40354



RIFFT SAFETY

0800 474 338



www.rifftsafety.co.nz

